

Superlite Outriggers Instruction Tutorial

Congratulations on your purchase of Superlite outriggers. You can ski with the confidence of knowing that your outriggers were manufactured by Enabling Technologies, the foremost name in the outrigger market for decades.

Box Contents:

- 2 complete lower tubes – including ski tip, string, and string adjustor
- 2 upper tubes – including grip
- 2 cuffs with post
- 1 pair quick clips w/ eyelet
- 4 bolts with nuts

1. Insert lower leg into upper tube with string and del rin pin facing the same direction as hand grip. Align adjusting holes for correct height. Insert quick clip with eyelet through both holes. Make sure that eyelet lines up with hand grip and del rin pin.
2. Run string through eyelet on quick clip and through end cap at the end of the hand grip. Tie a knot in the string as close to the end cap as possible. If string is not long enough, adjust length with string adjustor. After tying the knot, pull on string adjustor to tighten string.
3. Insert cuff post with cuff into upper tube. Align cuff post with adjustor holes. After determining desired location, insert quick clip or bolt. When worn, the opening on the cuff should be to the inside of the arm.

Outrigger Tips and Tricks

1. To adjust the opening of the cuff, heat cuff (boiling water or a hair drier work well). Then wrap the cuff around something with the diameter that you are seeking. For example, a softball or coffee mug. Use a rubber band or string to tighten cuff around the object.
2. ET suggests replacing quick clip with bolts once desired lengths are determined. This keeps adjustor holes from egging out or rattling.
3. For sticking del rin pins, apply WD 40 or other lubricant.